

# CHCNAV ALPHA AIR 450 APPLICATION CASE

TOPOGRAPHIC MAPPING WITH UAV LIDAR TO INCREASE THE OUTPUT OF MINING OPERATIONS.



MAPPING & GEOSPATIAL – JUNE 2022



# WHY LIDAR SURVEY IS THE GO-TO SOLUTION FOR OPTIMIZING MINING OPERATIONS?



Mines are in constant production, resulting in an ever-changing terrain, and therefore require the collection and processing of large amounts of information with great accuracy. In the case of coal or iron ore mines, inaccurate measurements result in inefficient operations and can even affect the outcome and quality of the project.

Traditional measurement methods mainly use GNSS, total station, and other equipment, requiring surveyors to go to the site to perform the measurements, but it is typically not safe and time-consuming. In addition, the data results cannot be visualized globally; they are just represented by several single 3D measured points, which leads to difficulties in meeting the digital requirements of modern mines for rapid updates. But UAV LiDAR solutions can help overcome the challenging topography, hazardous conditions, and other typical mine site issues.

Light Laser Detection and Ranging (LiDAR) is one of the most cutting-edge technologies in the field of surveying and mapping today. Installed on a drone for mine surveys, it allows to measure the three-dimensional coordinates of objects on the ground, to penetrate the vegetation and to apply a point cloud filtering method to generate a high precision DTM. Aerial surveying eliminates safety concerns for on-site surveyors, and it takes only minutes to hours to complete the measurement of the entire site, significantly improving production efficiency.

The case study was carried out in a typical mine site environment to produce an actual three-dimensional model of the current site, replacing the typical two-dimensional CAD drawings and photos. The BB4 UAV, AlphaAir 450 LiDAR scanner and CoPre software from CHCNAV and Global Mapper software from Blue Marble Geographics were used in this project.





Figure 1. Aerial view of the mining site



## HOW TO PERFORM A LIDAR SURVEY OF A MINE SITE IN 3 STEPS?

Step 1. Perform the airborne survey with a high-performance package, such as CHCNAV's BB4 UAV and AA450 LiDAR.

The **BB4 UAV** is a high-end unmanned aircraft system designed for professional industrial applications. The hull with pre-installed arms and antennas reduces the time required for setup, making the platform ready for use in just 2 minutes with the option to install various cameras and lidar with up to 7 kg payload.

**AA450** is an airborne LiDAR system with a built-in high-precision IMU, GNSS, advanced 3D scanner, and industrial-grade 26 MP camera, used for mining survey, power line inspection, topographic mapping, agricultural and forestry surveys, and more. This all-in-one, lightweight, rugged and easy-to-use system offers high precision capabilities at an affordable price point. It is bundled with the CoPre, a powerful and accurate 3D point cloud processing software.



Figure 2. BB4 UAV and AA450 LiDAR scanner performing aerial survey



Step 2. Data processing to generate the 3D point cloud of the site

Transfer the raw LiDAR and camera data, merge it with INS trajectory using CoPre software and generate the files in LAS format in the required coordinate system.

**CoPre** is a desktop software, that provides instant access to all raw data from CHCNAV LiDAR systems. CoPre supports one-button click automated processing of point cloud, picture georeferencing, point cloud colorization, depth map, and results output. For experts who value the quality of data, CoPre provides advanced processing. It can solve the layering problem of multiple point clouds, improve relative accuracy by efficient strip adjustment algorithm, and improve the absolute precision of the point cloud with GCPs.



Figure 3. Point cloud of a part of mining site generated in CoPre Software

It is also possible to colorize the point cloud with true colors using the CoPre's one-click shading function during processing. The image processing module can automatically organize photos and color point clouds in the background.

### 



Figure 4. Mining site point cloud with the RGB colorization made in CoPre Software



Step 3. Calculate the mine site volume using the Global Mapper software.

Import of point cloud data, extraction of ground point cloud parts, selection or import of range lines to be measured, generation of volume calculation results and report output.



Figure 5. The volume calculation results for mining site in Global Mapper software.

Table 1. The final parameters of the mining site area, extracted from the report

Total Volume	545. 27424 m <sup>3</sup>
Total Enclosed Area	0.004137 km²
Total Length Perimeter	267.32 m



# MINE SITE MANAGERS PRAISE THE VALUE OF UAV LIDAR SURVEYS IN THEIR DAY-TO-DAY OPERATIONS

The adoption of drone-based 3D data acquisition technologies is now a necessary element in optimizing mining operations. CHCNAV's UAV LiDAR solutions play an active role in the digitizing of mine maintenance and operations by providing access to efficient acquisition and processing of multi-source 3D spatial data.

**CHCNAV's Mobile** Mapping Division makes this digitization process accessible and affordable by merging technologies, from millimeter-precision GNSS sensors to ultra-precise long-range scanners, for massive 3D data acquisition over small or large areas.

### 

**CHC Navigation (CHCNAV)** creates innovative GNSS navigation and positioning solutions to make customers' work more efficient. CHCNAV products and solutions cover multiple industries such as geospatial, construction, agriculture and marine. With a presence across the globe, distributors in more than 120 countries and more than 1,500 employees, today CHC Navigation is recognized as one of the fastest-growing companies in geomatics technologies. For more information about CHC Navigation [Huace:300627.SZ], please visit our **website**.

#### **CHC** Navigation

Building D, NO. 599 Gaojing Road, Qingpu District 201702 Shanghai China

marketing@chcnav.com | www.chcnav.com